

Caribak™ SUP/Surfboard Carrier Kit Instructions

1. Wipe dirt and dust from roof top of vehicle.
2. Place foam blocks on ground and place board on top. (If transporting multiple boards, place spacer block on top of board aligned with foam block below.) Use block straps to secure both foam and spacer blocks to board.
3. Load and center board onto car roof. If car has rack, snap blocks onto rack.
4. Be careful to ensure sufficient support provided by the roof under each block. Reposition blocks on roof as needed to stabilize board as close to front and rear of car as possible. Fully tighten block straps.
5. Open either front or rear door on each side of vehicle and place utility strap over hull through the car and buckle. Tighten strap. Do not over-tighten which can result in deformation of foam blocks, board, or denting of roof.
6. Move to rear and repeat previous step with single remaining center strap.
7. Always recheck tie-downs before driving the vehicle. It is advised to check the stability of the load and tension of the straps after 2-to-5 miles of driving. Keep rechecking the straps during the trip.
8. Grab the board(s) and shake it to determine if board is secured to the roof. Retighten if necessary.
9. Visit www.Caribak.com for detailed installation instructions.

WARNING

This carrier has been designed to attach securely to an automobile. However, your attachment to the car is critical and beyond the control of the manufacturer. The user of this carrier must secure it properly to the car, check its attachment before each use, and inspect carrier parts for wear. The manufacturer is not responsible for and does not guarantee the attachment of this carrier to any automobile, and is not liable for any damages resulting from its attachment. The liability of the manufacturer is limited to the purchase price of the merchandise which proves defective in materials and/or workmanship.